



BULLET BRAKE - Usage Instructions

Install and Usage Videos Available at www.bulletbrake.com/install

1. After installing the BULLET BRAKE, using the BULLET BRAKE is simple to do.
2. First apply the front brake lever enough to hold the bike in position.
3. Then press the button on the BULLET BRAKE in until it is seated.
4. Then release the front brake lever.
5. Then release the button on the BULLET BRAKE.
6. Now the BULLET BRAKE is set.
7. Test the holding pressure buy trying to move the bike if the bike can be moved apply the front brake lever to disengage the BULLET BRAKE repeat steps 2-5 again using more pressure on the front brake lever.
8. Once you have found the pressure that holds the bike that's all the pressure you will need to apply every time you use the BULLET BRAKE. *****NOTE*** DO NOT OVERAPPLY FORCE to the BULLET BRAKE or "Double Pump" the BULLET BRAKE** by holding the button in while squeezing the lever over and over. This can damage the BULLET BRAKE!
9. To disengage the BULLET BRAKE simply apply the front brake lever until the BULLET BRAKE button pops out and you're ready to go! If you forget to release the BULLET BRAKE and try to move the bike, the front end will simply drop down reminding you that the BULLET BRAKE is still engaged and can be quickly released.

Thank you for purchasing the BULLET BRAKE!